



Working with the measured value display unit

ND 282


Actual value and input display

(7-segment LED,
9 decades and sign)

- **Select datum**
- Page backward in parameter list

- **Confirm entry value**
- Set display to value from P79 (P80!)

Numeric keypad



Status display

- **Switch display to:**
MIN / MAX / DIFF / ACTL / START / PRINT
- Go to parameter list after switch-on
- Page forward in parameter list

- **Clear entry**
- Reset to zero (P80!)
- CL plus MOD: parameter list
- CL plus 2-digit number: select parameter
- Clear parameter entry and show parameter number

- **Algebraic sign**
- Decrease parameter value
- **Decimal point**
- Increase parameter value


Indicator	Meaning
REF	If the decimal points have stopped blinking: Reference mark was crossed over—datum points are now stored in nonvolatile memory. Blinking: Waiting for operator to press ENT or CL.
in.	Position values displayed in inches.
↓1 / ↓2	Datum 1 / Datum 2 currently active.
PRINT	Blinking: Display unit is waiting for ENT for data output.
SET	Blinking: Waiting for operator to confirm entry values.
< / = / >	Sorting mode: Measured value less than lower limit / within tolerances / greater than upper limit.
MIN / MAX DIFF / ACTL	Measuring series: Minimum / Maximum / largest difference (MAX-MIN) / current measured value. Blinking: Waiting for confirmation of value to be displayed.
START	Measuring series in progress. Blinking: Waiting for start signal for measuring series.


The ND 282 is designed primarily for use with HEIDENHAIN **MT Length Gauges**. MT length gauges feature **one** reference mark. When the reference mark is crossed over, it generates a signal identifying that position as a reference point.


After switch-on, simply crossing over the reference mark restores the relationship between axis positions and display values as it was last defined by datum setting.

It is also possible to use other photoelectric linear encoders (see "Parameter Settings for HEIDENHAIN Linear Encoders"). These encoders have one or more reference marks, which may also be *distance-coded*. With distance-coded reference marks, a maximum traverse of only 20 mm suffices to re-establish the datum.

Switch-On

	Turn on the power (switch located on rear panel). <ul style="list-style-type: none">• Display shows <code>ENT. . . CL</code>• REF indicator blinks.• Data interface shows ERROR 07
Ent . . . CL	


	Switch on reference mark evaluation. <ul style="list-style-type: none">• Display shows the value last assigned to the reference mark position.• REF indicator glows.• Decimal point blinks.
5 , 6 9 7	


	Cross over reference mark. Move the axis until the display becomes active and the decimal point no longer blinks.
--	---

If you do **not** wish reference mark evaluation, press **CL** instead of ENT.

Setting the Datum

The datum setting procedure assigns a display value to a specific axis position. The ND 282 allows you to set two separate datum points.

	Select datum 1 or 2.
---	-----------------------------

	Enter a value , such as 40.
4 0	

	Confirm entered value.
---	-------------------------------

You can switch from one datum to the other at any time. Use datum 2 when you want to display incremental dimensions.

Measuring Series

The ND 282 display unit can calculate and display one of the following values from a measuring series:

Smallest value (MIN), largest value (MAX), difference between largest and smallest value (DIFF), last value measured (ACTL)

A new value is captured every 550 μ s during a measuring series.

To start a measuring series:

- Press the **MOD** key repeatedly until the desired indicator starts blinking.
Example: to display the largest value, press MOD until MAX blinks.
- Confirm your selection by pressing ENT.
- Press MOD repeatedly until the START indicator blinks.
- Start the measuring series by pressing ENT.

You can switch between MIN, MAX, DIFF and ACTL at any time:

- Press MOD until the desired indicator blinks, then confirm with ENT. **Or**
- Use operating parameter P21 (see list of operating parameters).

Note:

When the switching input for remote control of the measuring series is active (pin 6 of D-sub connection EXT), you **cannot** switch over the display as described here.

To abort a measuring series and restart:

- Press MOD until START blinks, then confirm with ENT.

To end a measuring series:

- Press MOD until the glowing indicator blinks, then confirm with ENT.

It is also possible to start a measuring series and switch over the display with a **switching input over the D-sub connection EXT** (see that section).

Sorting and Tolerance Check Mode

In this mode, the display value is compared with an upper and a lower limit value. Status indicators and the switching outputs at the D-sub connection EXT indicate whether the display value is less than the lower limit, greater than the upper limit, or between the two limit values.

Indicator	Meaning
=	Measured value is between the limit values
<	Measured value is less than the lower limit value
>	Measured value is greater than the upper limit value

Operating parameters for the sorting mode:

- P17: sorting on / off, P18, P19: limit values

Distance-to-go Mode

The standard setting for the display unit is to show the encoder position value.

Code number 246 582 provides access to the distance-to-go mode.

"Traverse to zero" with distance-to-go display

- Select datum 2.
- Enter the nominal position.
- Move the axis to the display value zero.

In distance-to-go mode the trigger outputs A1 (Pin 15) and A2 (Pin 16) change their meaning: they become symmetrical to the display value zero.

Data Output

There are four ways to output data:

- Press the MOD key until the PRINT indicator starts blinking (only possible with "slow" data output), and start data output with the ENT key; **or**
- Send measuring data to the data output periodically; **or**
- Input a latch command over the D-sub connection EXT; **or**
- Input a latch command over the BCD connection.

Interface mode (see operating parameter P53)

Slow: Output display values

Fast: Output instantaneous values referenced to datum 1
(MIN/MAX/DIFF display values are not output)

A **connecting cable** (to a PC, for example) is available from HEIDENHAIN (Id.-Nr. 206 420 ..); cable length up to 10 m (32.8 ft).

Operating parameters for data output: P23, P53 to P57

"AMP-CHAMP" connection (36-pin, female)

Pins				Assignment
2 ⁰	2 ¹	2 ²	2 ³	
1	2	3	4	Decade 1
5	6	7	8	Decade 2
9	10	11	12	Decade 3
13	14	15	16	Decade 4
17	18	19	20	Decade 5
21	22	23	24	Decade 6
25	26	27	28	Decade 7
29	30	31	32	Decade 8

Pins	Assignment
33	Sign
34	Ready
35	Meas. val. output
36	0V

Output levels **Low:** $U \leq 0.4 \text{ V}$ with $I \leq 6 \text{ mA}$ **High:** $U \geq 3.8 \text{ V}$ with $I \leq 2.6 \text{ mA}$
The output signals are TTL-compatible.

Latch levels **Low:** $U \leq 0.9 \text{ V}$ with $I_{\text{max}} \leq 6 \text{ mA}$ **High:** $U \geq 3.9 \text{ V}$; **or**
TTL levels (internal 10 k Ω pull-up resistor).

Signal transit times

The following table lists **approximate** signal transit times. If you use the slow data output and run functions such as measuring series or inch display at the same time, the actual transit times can be twice as long as those listed here.

Concurrent data output (P55 <i>ACTL</i>)			
Mode	P53	Latch time	Data output after
Fast	<i>FAST</i>	P54	Value from P54 / 2
Slow	<i>SLOW</i>	$t \leq 30 \text{ ms}$	$t \leq 8 \text{ ms}$

Data output after external latch (P55 <i>STOP</i> or <i>HOLD</i>)							
Mode	P53	Min. pulse duration		Measured value stored after			
		Pulse / BCD	Contact	BCD	Pulse	Contact	
Fast	<i>FAST</i>	3 μs	7 ms	0.3 μs	1.1 μs	4.8 ms	
Slow	<i>SLOW</i>	$t \geq 8 \text{ ms}$	$t \geq 13 \text{ ms}$	0.3 μs	1.1 μs	4.8 ms	
				Data output		Latch again after	
						Pulse/BCD	Contact
Fast	<i>FAST</i>	$\leq 0.3 \mu\text{s}$ after internal latching		3 μs		7 ms	
Slow	<i>SLOW</i>	$\leq 7.5 \text{ ms}$ after internal latching		3 μs		7 ms	

D-Sub Connection EXT (25-pin, male)



Danger to internal components!

Voltage sources for external circuitry must conform to the recommendations in EN 50 178 for low-voltage electrical separation. Connect inductive loads only with a quenching diode parallel to the inductance.



Use only shielded cable!

Connect the shield to the connector housing.

	Pin	Function	Pin	Function
Outputs	15	Meas. value \geq trigger limit A1 (P62)	1	0 V
	16	Meas. value \geq trigger limit A2 (P63)	10	0 V
	17	Meas. value $<$ lower sorting limit (P18)	12	Do not assign
	18	Meas. value $>$ upper sorting limit (P19)	13	Do not assign
	19	Error (see <i>Error Messages</i>)	11	Vacant
Inputs	14	Display value is zero	20	Vacant
	2	Reset display to zero, clear error message	21	Vacant
	3	Preset display to value from P79		
	25	Cross over reference marks		
	4	Ignore reference mark signals		
	5	Start measuring series		
	6	Remote selection of display val. f. meas. ser.		
	7	Display minimum value from meas. series		
	8	Display maximum value from meas. series		
	9	Display MAX – MIN diff. from meas. series		
	22	Pulse: output measured value		
	23	Contact: output measured value		
	24	Deactivate BCD data output		

Display current measured value (**ACTL**): Inputs 7, 8 and 9 are not active, or more than one of these inputs is active

Signal levels	Low		High	
Inputs	$-0.5 \text{ V} \leq U \leq 0.9 \text{ V}$	$I \leq 6 \text{ mA}$	$3.9 \text{ V} \leq U \leq 15 \text{ V}$	
Outputs	$U \leq 0.4 \text{ V}$	$I \leq 100 \text{ mA}$	$U \leq 32 \text{ V}$	$I \leq 10 \mu\text{A}$


Description of input and output signals

Input signals

- Triggering by make contact against 0 V **or** Low level over TTL component
- Internal pull-up resistor 1 k Ω
- Min. pulse duration: $t \geq 30 \text{ ms}$, for fast reset/preset: $t \geq 30 \mu\text{s}$
- Min. pulse interval: $t \geq 30 \text{ ms}$, for reset/preset: $t \geq 1,5 \text{ ms}$; for fast reset/preset: $t \geq 30 \mu\text{s}$
- Delay for zero reset/preset: fast data output $t_d \leq 25 \mu\text{s}$; slow data output $t_d \leq 2 \text{ ms}$

Output signals

- Open collector outputs, active Low
- Signal output delay: $t_d \leq 8 \text{ ms}$
- Zero crossover signal minimum duration, trigger output A1, A2: $t_0 \geq 180 \text{ ms}$



Note that these times increase if additional features are active (such as sorting).

Data Output and Display Freeze by Output Signal

The effect of a signal for measured value output is defined in operating parameter P55.

- ▶ **Concurrent display:** No output value freeze. The output describes the current measured value (*ACTL*).
- ▶ **Frozen display:** The output value is frozen and is updated with each signal for measured value output (*HOLD*).
- ▶ **Frozen/concurrent display:** The output value freezes only as long as the signal is present (*STOP*).

P23 defines whether the display shows the current measured value (*ACTL*) **or** the value at the data output (*BCD*).

Error Messages

To clear error message ERROR:

When you have removed the cause of the error,

- ▶ press CL.

Message	Cause and Effect
<i>ERROR 01</i>	Last measured value not yet latched ¹⁾
<i>ERROR 04</i>	Attempt to reset to zero or preset not permissible. The display is not reset or preset.
<i>ERROR 10</i>	Incorrect input value
<i>ERROR 11</i>	Overflow caused by external preset
<i>ERROR 12</i>	Value entered cannot be displayed
<i>ERROR 13</i>	Overflow, trigger limit 1
<i>ERROR 14</i>	Overflow, trigger limit 2
<i>ERROR 15</i>	Overflow, lower sorting limit
<i>ERROR 16</i>	Overflow, upper sorting limit
<i>ERROR 50</i>	Encoder signal too weak ¹⁾ (encoder may be contaminated)
<i>ERROR 51</i>	Input frequency too high for encoder input ¹⁾ (will occur for example when traverse speed too high)
<i>ERROR 53</i>	Internal counter overflow ¹⁾
<i>ERROR 55</i>	Error while crossing over reference marks ¹⁾
<i>ERROR 80</i>	To clear the error message: Switch off the display unit.
<i>ERROR 83</i>	Should any of these error codes recur, contact your HEIDENHAIN service agency.
<i>ERROR 84</i>	
<i>ERROR 86</i>	
<i>ERROR 99</i>	Erase the operating parameters.

If **all decimal points light up**, the measured value is too large or too small.
In this case, set a new datum **or** retract.

If **all sorting indicators light up**, this means that the upper sorting limit is less than the lower limit.

¹⁾ These errors are significant for a connected device. The error signal (pin 19) at the D-sub connection EXT is active.

Operating Parameters

The parameters are divided into "user parameters" and "protected operating parameters," which can only be accessed by entering a code number.

User parameters

User parameters are operating parameters that you can change **without** entering the code number: They are designated P00 to P30, P79, P86

Calling user parameters

To call user parameters **immediately after switch-on**:

- Press the MOD key as long as `ENT. . . CL` is visible in the display.

To call user parameters **during operation**:

- Press and hold the CL key, then press MOD.

To go **directly** to a specific user parameter:

- Press and hold the CL key, then press the first digit of the parameter number.
- Release both keys and press the second digit.

Protected operating parameters

Before you can change protected operating parameters you must enter the **code number 95 148** through `P00 CODE`: They **remain** accessible until you switch off the position display.

To page through the parameter list

- **Forward** paging: Press the MOD key.
- **Backward** paging: Press the `+1 / +2` key.
By paging on, you automatically enter any change you've made in a parameter.

To change operating parameters

- Increase the parameter value with the decimal point key, **or**
- Decrease the parameter value with the minus key, **or**
- Enter the numerical value for the operating parameter, e.g. for P79 (`SET` blinks).

To correct your entries and show the parameter designation

- Press the CL key.

To exit the operating parameters

- Press ENT. All changes made become effective.

Operating Parameter List

Parameter	Meaning	Function / Effect	Setting
<code>P00 CODE</code>	To change a protected operating parameter, enter code number 95 148 .		
<code>P01 INCH</code>	Unit of measurement	Display in millimeters	<code>OFF</code>
		Display in inches	<code>ON</code>
<code>P17 CLASS</code> <i>Classification</i>	Sorting mode	Sorting on	<code>CLASS ON</code>
		Sorting off	<code>CLASS OFF</code>
<code>P18 CLASS</code>	Lower sorting limit	(ensure that P18 < P19)	
<code>P19 CLASS</code>	Upper sorting limit	(ensure that P19 > P18)	
<code>P21 SDOF</code> <i>Storage</i>	Value displayed for measuring series	<code>MIN</code> <code>ACTL</code> <code>MAX</code> <code>DIFF</code>	<code>OFF</code>
<code>P23 DISP</code> <i>Display</i>	Display value	Measured value (Actual)	<code>ACTL</code>
		Value at data output	<code>BCD</code>
<code>P30 DIR</code> <i>Direction</i>	Counting direction	Normal (Positive)	<code>POS</code>
		Inverse (Negative)	<code>NEG</code>


Parameter	Meaning	Function / Effect	Setting
P32 <i>Subd</i> Subdivision	Subdivision of encoder signals 200, 100, 50, 40, 20, 10, 8, 5, 4, 2, 1, 0.8, 0.5, 0.4, 0.2, 0.1		
P33 <i>STEP</i>	Counting mode	0-1-2-3-4-5-6-7-8-9-0	1
		0-2-4-6-8-0	2
		0-5-0	5
P38 <i>DEC</i> Decimal point	Places after decimal 1 / 2 / 3 / 4 / 5 (up to 7 with inch display)		
P43 <i>REF</i>	Reference marks	One reference mark	SINGLE
		Distance-coded with 500 • SP (SP = signal period)	500
		Distance-coded with 1000 • SP (e.g. for LS 303 C / LS 603 C)	1000
		Distance-coded with 2000 • SP	2000
		Distance-coded with 5000 • SP	5000
P44 <i>REF</i>	Reference mark evaluation	Evaluation	REF ON
		No evaluation	REF OFF
P45 <i>ENCd</i> Encoder	Encoder monitoring	No monitoring (Alarm Off)	ALARM OFF
		Contamination	ALARM C
		Frequency	ALARM F
		Contamination and frequency	ALARM CF
P53 <i>bCd</i>	Speed of data output	Slow	SLOW
		Fast, storage rate: P54	FAST
P54 <i>bCd</i>	Latch speed	0.2 / 0.4 / 0.8 / 1.6 / 3.2 / 6.4 / 12.8 / 25.6 [µs]	
P55 <i>bCd</i>	Data output from output signal	Data output concurrent (Actual)	ACTL
		Frozen	HOLD
		Frozen/concurrent	STOP
P56 <i>bCd</i>	Sign level	Low = Minus (Sign Low)	SIGN LO
		High = Minus (Sign High)	SIGN HI
P57 <i>bCd</i>	Behavior w/o latch signal	Data output always active	TRIS OFF
		Output high impedance (Tristate)	TRIS ON
P62 <i>A1</i>	Trigger limit 1	Enter numerical value	
P63 <i>A2</i>	Trigger limit 2	Enter numerical value	
P79 <i>PRSt</i> Preset	Value for datum	Enter numerical value for datum setting via switching input or with the ENT key	
P80 <i>SEt</i>	Display reset/preset	No zero reset/preset with CL/ENT	SEt OFF
		Zero reset with CL (Set Zero), no preset with ENT	SEt ZERO
		Zero reset with CL and preset with ENT to value in P79	PRESEt
P82 <i>NESt</i> Message	Display after switch-on	[ENT]...[CL] message displayed	NESt ON
		[ENT]...[CL] message not displayed	NESt OFF
P84 <i>bCd</i>	Output of error signal	Error signal sent to data output	ERRD ON
		Error signal not sent to data output	ERRD OFF
P85 <i>REF</i>	External REF	REF over D-sub connection EXT	EXT ON
		No REF over EXT connection	EXT OFF
P86 <i>MOd</i> Mode	First status indicator after MOD is pressed [START] [PRINT] [MIN] [ACTL] [MAX] [DIFF]		
P87 <i>FSEt</i> Fast Set	Fast repeated external reset/preset	Fast external reset/preset (setting of P53:FAST) REF mode, datum 2 and measuring series are not usable	ON
		No fast preset	OFF

Parameter Settings for HEIDENHAIN Linear Encoders

Model	Signal period [µm]	Reference marks	P 43	Display step (unit: P01)		The following settings apply for mm:		
				mm	inches	Subdi- vision	Count. mode	Decimal places
						P32	P33	P38
CT	2	one	single	0,0005	0,00002	4	5	4
MT_xx01				0,0002	0,00001	10	2	4
LIP 401		none	-	0,0001	0,000005	20	1	4
		one	single	0,00005	0,000002	40	5	5
				<i>Recommended only for LIP 401</i>				
				0,00002	0,000001	100	2	5
				0,00001	0,0000005	200	1	5
LF 103	4	one dist.c.	single 5000	0,001	0,00005	4	1	3
LF 401				0,0005	0,00002	8	5	4
LIF 101				0,0002	0,00001	20	2	4
LIP 501				0,0001	0,000005	40	1	4
LIP 101		one	single	<i>Recommended only for LIP 101</i>				
				0,00002	0,000001	200	2	5
MT xx	10	one	single	0,0005	0,00002	20	5	4
				0,0002	0,00001	50	2	4
				0,0001	0,000005	100	1	4
LS 303	20	one dist.c.	single 1000	0,01	0,0005	2	1	2
LS 603				0,005	0,0002	4	5	3
LS 106	20	one dist.c.	single 1000	0,001	0,00005	20	1	3
LS 406				0,0005	0,00002	40	5	4
LS 706								
ST 1201		none	-					
LB 302	40	one dist.c.	single 2000	0,005	0,0002	8	5	3
LIDA 10x				0,002	0,0001	20	2	3
				0,001	0,00005	40	1	3
				<i>Recommended only for LB 302</i>				
				0,0002	0,00001	200	2	4
LB 301	100	one dist.c.	single 1000	0,005	0,0002	20	5	3
				0,002	0,0001	50	2	3
				0,001	0,00005	100	1	3

Example: Set parameters for any encoder
 Linear encoder with signal period $s = 10 \mu\text{m}$
 Desired display step $a = 0,0001 \text{ mm}$
Subdivision $P32 = 0,001 \cdot s / a = 100$
Counting mode $P33 = 1$ (display counts 1, 2, 3 ...)
Places after decimal point of a : $P38 = 4$

Rear Panel




The X1, X33 and X41 interfaces comply with the recommendations in EN 50 178 for separation from line power.

Installation

You can mount the display unit to a flat surface with M4 screws (see illustration at right).

The display units can also be stacked. Adhesive inserts (included in delivery) prevent them from sliding.



Power Supply and Connection



Danger of electrical shock!

Unplug the power cord before opening the housing. Connect a protective ground. This connection must never be interrupted.



Danger to internal components!

Do not engage or disengage any connections while the unit is under power. Use only original replacement fuses.

Primary-clocked power supply.

Voltage range 100 V to 240 V (–15% to +10 %) **Frequency** 48 Hz to 62 Hz

Power consumption typ. 8 W **Line fuse** F 1 A (in unit)

Minimum cross-section of power cable: 0.75 mm²



To increase the noise immunity, connect the ground terminal on the rear panel to the central ground point of the machine. (Minimum cross-section 6 mm²)

Ambient Conditions

Temperature range Operation: 0° C to + 45° C (32° F to 113° F)
Storage: – 30° C to + 70° C (– 32° F to 158° F)

Rel. humidity Annual average: < 75%; maximum: < 90%

Weight 1.5 kg

DR. JOHANNES HEIDENHAIN GmbH

Dr.-Johannes-Heidenhain-Straße 5

D-83301 Traunreut, Germany

☎ (086 69) 31-0 · ☎ 56 832

☎ (086 69) 50 61

☎ **Service** (086 69) 31-12 72

☎ TNC-Service (086 69) 31-14 46

☎ (086 69) 98 99